








A		Ø10x40mm	16	D		M6x10x14mm	14
B		Ø16x60mm	10	G		4.0x60mm	20
C		M6x120mm	14	H		4mm	1

1


2 x




2





3





4




5



6







7




Montage der Rutsche

Montage van de glijbaan - Montage du toboggan




A		Ø10x40mm	5	O		3.5x15mm	8
C		M6x120mm	1	L		Ø10	6
D		M6x100mm	1	M		Ø8	2
E		M6x90mm	1	N		4mm	1
F		M6x10x14mm	3	R		Ø10x30mm	2
G		M6x8x15mm	1	S		hook	2
J		3.5x35mm	6	T		6.3x40mm	1


1




2




3



4



5



Optionen

Opties - Options

